

FLX21.5

4010069049

Supplement for Wall mounting instructions

Step	Action	Figure
1	Use the provided drilling template or the wall mount itself to determine the drilling positions.	
2	To guarantee a stable fastening it is strongly recommended to use the 4 vertical fastening points (marked) on a stud frame or any other solid material.	
3	Drill 6 holes for the dowels: 10 mm diameter, at least 70 mm deep.	
4	Insert the dowels.	
5	Use the provided 4x countersunk head screws for the vertical fastening points.	
6	Use the provided 2x button head screws for the other fastening points. Use the provided washers.	

Pictures show sample configurations, real product may vary.

1/2

⚠ CAUTION



Risk of injury from falling components.

- Keep a safe distance from the device while it is being transported or installed.
- Make sure that the system is securely fastened.

Step	Action	Figure
7	Put the system on the wall mount.	
8	Attach it with the 3 remaining screws and the 3 nuts to the wall mount. Use washers on screw-side.	